

PO Box 518  
620 Applegate St.  
Philomath, OR 97370



(541) 929-5650  
Fax (541) 929-5277  
[www.wetlabs.com](http://www.wetlabs.com)

QC  
121  
ACC

## ECO CDOM Fluorometer Characterization Sheet

Date: 3/17/2010

S/N: BBFL2VMT-740

CDOM concentration expressed in ppb can be derived using the equation:

$$\text{CDOM (ppb)} = \text{Scale Factor} * (\text{Output} - \text{Dark Counts})$$

**Dark Counts**

**Digital**

**Scale Factor (SF)**

47 counts

**Maximum Output**

0.0903 ppb/count

**Resolution**

4130 counts

1.7 counts

Ambient temperature during characterization

21.1 °C

**Dark Counts:** Signal output of the meter in clean water with black tape over detector.

**SF:** Determined using the following equation:  $SF = x \div (\text{output} - \text{dark counts})$ , where  $x$  is the concentration of the solution used during instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

**Maximum Output:** Maximum signal output the fluorometer is capable of.

**Resolution:** Standard deviation of 1 minute of collected data.

QC  
121  
ACC

PO Box 518  
620 Applegate St.  
Philomath, OR 97370



(541) 929-5650  
Fax (541) 929-5277  
[www.wetlabs.com](http://www.wetlabs.com)

## ECO Chlorophyll Fluorometer Characterization Sheet

Date: 3/17/2010

S/N: BBFL2VMT-740

Chlorophyll concentration expressed in  $\mu\text{g/l}$  can be derived using the equation:

$$\text{CHL } (\mu\text{g/l}) = \text{Scale Factor} * (\text{Output} - \text{Dark counts})$$

<b>Dark counts</b>	<b>Digital</b> 50 counts
<b>Scale Factor (SF)</b>	0.0124 $\mu\text{g/l/count}$
<b>Maximum Output</b>	4130 counts
<b>Resolution</b>	1.5 counts
 Ambient temperature during characterization	 21.1 °C

**Dark Counts:** Signal output of the meter in clean water with black tape over detector.

**SF:** Determined using the following equation:  $SF = x + (\text{output} - \text{dark counts})$ , where x is the concentration of the solution used during instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

**Maximum Output:** Maximum signal output the fluorometer is capable of.

**Resolution:** Standard deviation of 1 minute of collected data.

The relationship between fluorescence and chlorophyll-a concentrations in-situ is highly variable. The scale factor listed on this document was determined using a mono-culture of phytoplankton (*Thalassiosira weissflogii*). The population was assumed to be reasonably healthy and the concentration was determined by using the absorption method. To accurately determine chlorophyll concentration using a fluorometer, you must perform secondary measurements on the populations of interest. This is typically done using extraction-based measurement techniques on discrete samples. For additional information on determining chlorophyll concentration see "Standard Methods for the Examination of Water and Wastewater" part 10200 H, published jointly by the American Public Health Association, American Water Works Association, and the Water Environment Federation.

QC  
121  
ACC

620 Applegate St.  
Philomath, OR 97370



Fax (541) 929-5277  
[www.wetlabs.com](http://www.wetlabs.com)

## Scattering Meter Calibration Sheet

3/17/2010

Wavelength: 650

S/N BBFL2VMT-740

Use the following equation to obtain "scaled" output values:

$$\beta(\theta_c) \text{ m}^{-1} \text{ sr}^{-1} = \text{Scale Factor} \times (\text{Output} - \text{Dark Counts})$$

- **Scale Factor for 650 nm** = 3.986E-06 (m<sup>-1</sup>sr<sup>-1</sup>)/counts
- **Output** = meter reading counts
- **Dark Counts** = 45 counts

Instrument Resolution = 1.7 counts 6.73E-06 (m<sup>-1</sup>sr<sup>-1</sup>)

### Definitions:

- **Scale Factor:** Calibration scale factor,  $\beta(\theta_c)/\text{counts}$ . Refer to User's Guide for derivation.
- **Output:** Measured signal output of the scattering meter.
- **Dark Counts:** Signal obtained by covering detector with black tape and submersing sensor in water.

Instrument Resolution: Standard deviation of 1 minute of collected data.



QC  
121  
ACC

# Instrument Checklist

Date: 3/18/10

S/N: BBFL2VMT-740

Order # 8313

**Contents:**

Description	Qty	Packed
■ ECO Meter	1	X
■ Calibration/Characterization Sheet	1	X
■ Repair/Modification Sheet	1	
■ Dummy Plug		
■ Lock Collar		
■ Anti-Static Shipping Bag	1	X
■ Protective End Cap	1	X
■ Pigtail with Lock Collar	1	
■ Spare Parts Card	1	X
■ Dummy Plug Switch	1	
■ CD (w/ECOVView, User's Guides, & Device Files)	1	
■ Test Cable	1	
■ Black Protective Cap	1	
■ White Saddle	1	

Checked by: JVS

Comments: \_\_\_\_\_